

Варианты крепления СНПЧ RDM Epson

EPSON R200/R220



EPSON R240



EPSON R800



EPSON R270




EPSON R290\R295\T50



EPSON R1800




EPSON R2400





EPSON C110T30





EPSON C86



EPSON C82



EPSON PictureMate





EPSON 950







EPSON 2400



EPSON 1290



EPSON 1410



EPSON 2100



EPSON CX3500\CX3700



EPSON CX5200



EPSON RX500



EPSON CX4300



EPSON CX3900






EPSON CX4200



EPSON CX7300



EPSON CX9300F\TX200\TX400



EPSON RX520



EPSON RX700




EPSON TX109



EPSON TX700W



EPSON TX800FW



Проводим шлейф вдоль передней панели



Проверьте соответствие цветов принтера и картриджами СНПЧ

